

## Installation Information for QCRD 30000

To prevent the fracturing of the shaft from excess side pressure when installing the dash pod, the belt must not be too tight, there should be play in the belt as per the diagram below.

Press the belt between finger and thumb, belt should not feel tight.

